

Zebra Pen Accessory Guide

The standard pen that ships with the tablet depends on the display type and form factor, the following pen types are available

- Short Active Pen
- Short Passive Pen
- Long Active Pen
- Long Passive Pen
- Long ePen (requires 1 x AAAA battery)

The ePen is only an **option** on the non-active XPAD displays, or non-active XSLATE/XBOOK with soft top handle. Note, the ePen should be tested before use as it's not the same experience as the traditional active stylus (Wacom), customers coming from a traditional active pen technology (i.e. F5m) may be disappointed in the performance of the ePen. As a general rule, if the customer wants to do any drawing or handwriting using the TIP (Tablet Input Panel or other 3rd party converter), then the Active VAD display is the best option.

Display options

- Standard - non-active 500 nit
 - Compatible pens
 - Passive
 - ePen
- VAD - non-active 1000 nit
 - Compatible pens
 - Passive
 - ePen
- Active VAD - (active Wacom 1000 nit)
 - Compatible pens
 - Active Wacom only

VAD = View Anywhere Display (1000 nit)





XSLATE VAD and Standard display (non-active) standard short pen



XBOOK VAD Active standard pen



XBOOK VAD and Standard display (non-active) standard **long** passive pen





XBOOK VAD and Standard display (non-active) **Optional** long ePen



XBOOK or XSLATE with Soft handle can use the long pens (stored in the soft handle). If Active VAD ordered then it is compatible with the long active stylus (top). If just VAD or Standard only (non-active) then either the ePen (bottom) or long passive pen (passive pen not pictured).

